



NOTE: SOME COMMUNITIES, MUNICIPALITIES, COUNTIES REQUIRE A BACKFLOW PREVENTER OR VACUUM BREAKER WITH THE INSTALLATION OF A HANDSHOWER. CHECK YOUR LOCAL PLUMBING CODES!

- SEE OVER FOR IMPORTANT INFORMATION -

